Table of Contents

Table of Contents 1
Usage Notice 2
Precautions 2
Introduction 4
Product Features 4
Package Overview 5
Product Overview 6
Main Unit 6
Control Panel 7
Connection Ports 8
Remote Control with Laser Pointer 9
Installation 10
Connecting the Projector 10
Powering On/Off the Projector 11
Powering On the Projector 11
Powering Off the projector 12
Warning Indicator 12
Adjusting the Projected Image 13
Adjusting the Projector Image Height 13
Adjusting the Projector Zoom / Focus 14
Adjusting Projected Image Size 14
User Controls 15
Control Panel & Remote Control 15
On-Screen Display Menus 18
How to operate 18
Language(Computer/Video Mode) 19
Color (Computer/Video Mode) 20
Image (Computer/Video Mode) 22
Audio (Computer/Video Mode) 25
Management (Computer/Video Mode) 26
Appendices 29
Troubleshooting 29
Replacing the lamp 33
Specifications 34
Compatibility Modes 35

Downloaded From projector-manual.com Acer Manuals

Usage Notice

Precautions

Follow all warnings, precautions and maintenance as recommended in this user's guide to maximize the life of your unit.

⚠**Warning-**	Do not look into the projector's lens when the lamp is on. The bright light may hurt your eyes.
⚠**Warning-**	To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
⚠**Warning-**	Please do not open or disassemble the product as this may cause electric shock.
⚠**Warning-**	When changing the lamp, please allow unit to cool down, and follow all changing instructions.
⚠**Warning-**	This product will detect the life of the lamp itself. Please be sure to change the lamp when it shows warning messages.
⚠**Warning-**	Reset the "Lamp Hour Reset" function from the On Screen Display "Management" menu after replacing the lamp module (refer to page 26)
⚠**Warning-**	When switching the projector off, please ensure the projector completes its cooling cycle before disconnecting power.
⚠**Warning-**	Turn on the projector first and then the signal sources.
⚠**Warning-**	Do not use lens cap when projector is in operation.
⚠**Warning-**	When the lamp reaches the end of its life, it will burn out and may make a loud popping sound. If this happens, the projector will not turn back on until the lamp module has been replaced. To replace the lamp, follow the procedures listed under "Replacing the Lamp".

Downloaded From projector-manual.com Acer Manuals

Usage Notice

Do:

- Turn off the product before cleaning.
- Use a soft cloth moistened with mild detergent to clean the display housing.
- Disconnect the power plug from AC outlet if the product is not being used for a long period of time.

Don't:

- Block the slots and openings on the unit provided for ventilation.
- Use abrasive cleaners, waxes or solvents to clean the unit.
- Use under the following conditions:
  - In extremely hot, cold or humid environments.
  - In areas susceptible to excessive dust and dirt.
  - Near any appliance that generates a strong magnetic field.
  - Place in direct sunlight.

Downloaded From projector-manual.com Acer Manuals

Product Features

This product is an SVGA single chip 0.55" DLP™ projector. Outstanding features include:

- True SVGA, 800 x 600 addressable pixels
- Single chip DLP™ technology
- NTSC3.58/NTSC4.43/PAL/SECAM and HDTV compatible (480i/p, 576i/p, 720p, 1080i)
- High-tech DVI connection for digital signal with HDCP function and supports 480p, 576p, 720p and 1080i (Optional)
- Full function remote control with laser pointer
- User friendly multilingual on screen display menu
- Advanced digital keystone correction and high quality full screen image re-scaling
- User friendly control panel
- SXGA, XGA compression and VGA re-sizing
- Mac compatible

Downloaded From projector-manual.com Acer Manuals

Package Overview

This projector comes with all the items shown below. Check to make sure your unit is complete. Contact your dealer immediately if anything is missing.

Projector with lens cap

Power Cord 1.8m

VGA Cable 1.8m

Composite Video Cable 2.0m

USB Cable 1.8m

S-Video Cable 1.8m

Audio Cable Jack /Jack 1.8m

VGA to Component/ HDTV Adapter

Remote Control with Laser Pointer

2 x Battery

Carrying Case

User's Guide

Quick Start Card

Downloaded From projector-manual.com Acer Manuals

Product Overview

Main Unit



NOTE

❖The color of the projector cover in this menu is for reference only. The color of real product is subject to change depending on marketing announcement.

1. Focus Ring
2. Zoom Ring
3. Zoom Lens
4. Elevator Button
5. Elevator Foot
6. Remote Control Receiver
7. Connection Ports
8. Power Socket
9. Control Panel

Downloaded From projector-manual.com Acer Manuals

Control Panel



1. Lamp Indicator LED
2. Temp Indicator LED
3. Power/Standby and Indicator LED (Power LED)
4. Source
5. Resync
6. Four Directional Select Keys
7. Menu

Downloaded From projector-manual.com Acer Manuals

Connection Ports



1. DVI Input Connector (for Digital singal with HDCP function) (Optional)
2. PC Analog Signal/HDTV/Component Video Input Connector
3. Audio Input Connector
4. S-Video Input Connector
5. Monitor Loop-through Output Connector (VGA-Out)
6. USB Connector
7. Remote Control IR Receiver
8. Composite Video Input Connector
9. Kensington™ Lock Port
10. 5V DC Output Jack (for attached dongle device) (for PD100 only)

Downloaded From projector-manual.com Acer Manuals

Remote Control with Laser Pointer



1. Transmit Indicator Light
2. Power
3. Empowering Key
4. Menu
5. Four Directional Select Keys
6. Laser Button
7. Digital Zoom
8. Keystone +
9. Keystone -
10. Page Up
11. Page Down
12. Resync
13. Hide
14. Source
15. Freeze
16. Laser Pointer

Downloaded From projector-manual.com Acer Manuals

Connecting the Projector



1. .....Power Cord
2. ..... VGA Cable
3. ..... Composite Video Cable
4. ..... USB Cable
5. .....VGA to Component/HDTV Adapter
6. .....S-Video Cable
7. .....Audio Cable Jack/Jack
8. ..... DVI Cable (Optional Accessory)
9. .....5V DC Output Jack for attached Dongle Device (PD100 only)

❖ *To ensure the projector works well with your computer, please make sure the timing of the display mode is compatible with the projector. Refer to the "Compatibility Modes" section on page 35.*

Downloaded From projector-manual.com Acer Manuals

Powering On/Off the Projector

Powering On the Projector

1. Remove the lens cap.
2. Ensure that the power cord and signal cable are securely connected. The Power LED will flash **red**.
3. Turn on the lamp by pressing "Power/Standby" button on the control panel.❶And the Power LED will turn **blue**.
4. Turn on your source (computer, notebook, video player ,etc.). The projector will detect your source automatically.

❖ *If the screen displays "No Signal", please make sure the signal cables are securely connected.*

❖ *If you connect multiple sources at the same time, using the "Source" button on the remote control or control panel to switch.*

NOTE

❖Turn on the projector first and then the signal sources.

Downloaded From projector-manual.com Acer Manuals

Powering Off the Projector

1. Press the "Power/Standby" button to turn off the projector lamp, you will see a message "Please press power button again to complete the shutdown process. Warning: DO NOT unplug while the projector fan is still running." displayed on the projector's screen. Press the "Power/Standby" button again to confirm, otherwise the message will disappear after 5 seconds.
2. The cooling fans continue to operate for about 60 seconds for cooling cycle and the Power LED will be quick **red flash**. When the Power LED becomes slow flashing, the projector has entered standby mode. If you wish to turn the projector back on, you must wait until the projector has completed the cooling cycle and has entered standby mode. Once in standby mode, simply press "Power/Standby" button to restart the projector.
3. Disconnect the power cord from the electrical outlet and the projector.
4. Do not turn on the projector immediately following a power off procedure.

Warning Indicator

- *When the "**LAMP**" indicator lights solid red, the projector will automatically shut itself down. Please contact your local reseller or service center.*

- *When the "**TEMP**" indicator lights solid red for about **20** seconds, it indicates the projector has been overheated. You will see a message "Projector Overheated. Lamp will automatically turn off soon." on the on-screen display. The projector will automatically shut itself down.*

  Under normal conditions, the projector can be switched on again after it has cooled down. If the problem persists, you should contact your local dealer or our service center.

- *When the "**TEMP**" indicator flashs red for about **30** seconds, you will see a message "Fan fail. Lamp will automatically turn off soon." on the on-screen display. Please contact your local dealer or our service center.*

Downloaded From projector-manual.com Acer Manuals

Adjusting the Projected Image

Adjusting the Projector Image Height

The projector is equipped with an elevator foot for adjusting the image height.

To raise the image:

1. Press the elevator button ❶.
2. Raise the image to the desired height angle ❷ , then release the button to lock the elevator foot into position.

To lower the image:

1. Press the elevator button.
2. Lower the image, then release the button to lock the elevator foot into position.

Downloaded From projector-manual.com Acer Manuals

Adjusting the Projector Zoom / Focus

You may turn the zoom ring to zoom in or out. To focus the image, rotate the focus ring until the image is clear. The projector will focus at distances from 4.9 to 39.4 feet (1.5 to 12.0 meters).



Adjusting Projection Image Size



Screen (Diagonal)	Max.	38.1"(96.8cm)	76.2"(193.6cm)	127.1"(322.7cm)	177.9"(451.8cm)	203.3"(516.3cm)	304.9"(774.5cm)
	Min.	34.7"(88.1cm)	69.3"(176.1cm)	115.6"(293.5cm)	161.8"(410.9cm)	184.9"(469.6cm)	277.3"(704.4cm)
Screen Size	Max.(WxH)	30.5" x 22.9" (77.4 x 58.1cm)	61.0" x 45.7" (154.9 x 116.2cm)	101.7" x 76.3" (258.2 x 193.6cm)	142.3" x 106.7" (361.4 x 271.1cm)	162.6" x 122.0" (413.0 x 309.8cm)	243.9" x 182.9" (619.6 x 464.7cm)
	Min.(WxH)	27.8" x 20.8" (70.5 x 52.9cm)	55.4" x 41.6" (140.9 x 105.7cm)	92.5" x 69.4" (234.8 x 176.1cm)	129.4" x 97.1" (328.7 x 246.5cm)	147.9" x 110.9" (375.7 x 281.8cm)	221.8" x 166.4" (563.5 x 422.6cm)
Distance		4.9'(1.5m)	9.8'(3.0m)	16.4'(5.0m)	23.0'(7.0m)	26.3'(8.0m)	39.4'(12.0m)

❖This graph is for user's reference only.

Downloaded From projector-manual.com Acer Manuals

Control Panel & Remote Control

There are two ways for you to control the functions: Remote Control and Control Panel.

Control Panel

Remote Control

Using the Control Panel

Power

- Refer to the "Power On/Off the Projector" section on pages 11-12.

Source

- Press "Source" to choose RGB, Component-p, Component-i, S-Video, Composite, DVI-D (Optional), Video and HDTV sources.

Menu

- Press "Menu" to launch the on screen display (OSD) menu. To exit OSD, press "Menu" again.
- Confirm your selection of items.

Four Directional Select Keys

- Use ▲ ▼ ◀ ▶ to select items or make adjustments to your selection.

Resync

- Automatically synchronizes the projector to the input source.

Downloaded From projector-manual.com Acer Manuals

User Controls

Using the Remote Control

Power

- Refer to the "Power On/Off the Projector" section on pages 11-12.

Empowering Key

Press "e" key to launch e mnu on screen display screen and use ▲ ▼ to select items.



Acer eView Management

- Press ▶ to launch "Acer eView Management" submenu.

"Acer eView Management" is for display mode selection. Please refer to On Screen Display Menus section for more detail.

Acer eTimer Management

- Press ▶ to launch "Acer eTimer Management" submenu.

"Acer eTimer Management" provides the reminding function for presentation time control. Please refer to On Screen Display Menus section for more detial.

Acer eOpening Management

- Press ▶ to launch "Acer eOpening Management" submenu.

"Acer eOpening Management" allows user to change the Startup screen their personalized image. Please refer to On Screen Display section for details.

Menu

- Press "Menu" to launch the on screen display menu. To exit OSD, press "Menu" again.

Four Directional Select Keys

- Use ▲ ▼ ◀ ▶ to select items or make adjustments to your selection.

Laser Button

- Aim the remote at the viewing screen, press and hold this button to activate the laser pointer.

Zoom

- Digital Zoom in/out.

Downloaded From projector-manual.com Acer Manuals

Keystone + / -

- Adjusts image distortion caused by tilting the projector (±16 degrees).

Page Up (Computer mode only)

- Use this button to page up. This function is only available when the projector is connected to a computer via an USB cable.

Page Down (Computer mode only)

- Use this button to page down. This function is only available when the projector is connected to a computer via an USB cable.

Resync

- Automatically synchronizes the projector to the input source.

Hide

- Momentarily turns off the video. Press "Hide" to hide image, press again to restore display of the image.

Source

- Press "Source" to choose RGB, Component-p, Component-i, S-Video, Composite Video , DVI-D (Optional)and HDTV sources.

Freeze

- Press "Freeze" to pause the screen image.

Downloaded From projector-manual.com Acer Manuals

On Screen Display Menus

The Projector has multilingual On Screen Display menus that allow you to make image adjustments and change a variety of settings. The projector will automatically detect the source.

How to operate

1. To open the OSD menu, press "Menu" on the Remote Control or Control Panel.
2. When OSD is displayed, use ◀ ▶ keys to select any item in the main menu. After selecting the desired main menu item, press ▼ to enter sub menu for feature setting.
3. Use ▲ ▼ keys to select the desired item and adjust the settings by ◀ ▶ key.
4. Select the next item to be adjusted in the sub menu and adjust as described above.
5. Press "Menu" on the Remote Control or Control Panel, the screen will return to the main menu.
6. To exit OSD, press "Menu" on the Remote Control or Control Panel again. The OSD menu will close and the projector will automatically save the new settings.

Downloaded From projector-manual.com Acer Manuals

Language (Computer / Video Mode)

Language

Choose the multilingual OSD menu . Use the ▲ or ▼ key to select your prefered language.

Press “Menu” on the Remote Control or Control Panel to finalize the selection.

Downloaded From projector-manual.com Acer Manuals

User Controls

Color (Computer / Video Mode)

Display Mode

There are many factory presets optimized for various types of images.

- Bright : For brightness optimization.
- PC : For computer or notebook.
- Video : For playing video in a bright environment.
- Theatre : For Home Theatre usage in a dark room.
- sRGB : For true-color optimization.
- User : Memorize user's settings.

Brightness

Adjust the brightness of the image.

- Press the ◀ to darken image.
- Press the ▶ to lighten the image.

Contrast

The contrast controls the degree of difference between the lightest and darkest parts of the picture. Adjusting the contrast changes the amount of black and white in the image.

- Press the ◀ to decrease the contrast.
- Press the ▶ to increase the contrast.

Color Temperature

Adjust the color temperature. At higher temperature, the screen looks colder; at lower temperature, the screen looks warmer.

Downloaded From projector-manual.com Acer Manuals

Color (Computer / Video Mode)

White Segment

Use the white Segment control to set the white peaking level of DMD chip. 0 stands for minimal segment, and 10 stands for maximum segment. If you prefer a stronger image, adjust towards the maximum setting. For a smooth and more natural image, adjust towards the minimum setting.

Degamma

Effects the represent of dark scenery. With greater gamma value, dark scenery will look brighter.

Saturation

Adjusts a video image from black and white to fully saturated color.

- Press the ◀ to decrease the amount of color in the image.
- Press the ▶ to increase the amount of color in the image.

❖"Saturation" and "Tint" functions are not supported under computer mode or DVI mode.

Tint

Adjusts the color balance of red and green.

- Press the ◀ to increase the amount of green in the image.
- Press the ▶ to increase the amount of red in the image.

Color R

Adjusts the red color.

Color G

Adjusts the green color.

Color B

Adjusts the blue color.

Downloaded From projector-manual.com Acer Manuals

User Controls

Image (Computer / Video Mode)

Keystone
Adjust image distortion caused by tilting projection. (±16 degrees)

Aspect Ratio
Use this function to choose your desired aspect ratio.

- Auto : Keep the image with original width-higth ratio and maxi mize the image to fit native horizontal or vertical pixels.
- 4:3 : The input source will be scaled to fit the projection screen.
- 16:9 : The input source will be scaled to fit the width of the screen.
- 480p : Provide the best display for a 480p 16:9 signal.

Source Lock
When source lock is turned off, the projector will search for other signals if the current input signal is lost. When source lock is turned on, it will “Lock” the current source channel before you press “Source” button on remote control for next channel.

Projection

- **Front-Desktop**
  The factory default setting.
- **Rear-Desktop**
  When you select this function, the projector reverses the image so you can project behind a translucent screen.
- **Front-Ceiling**
  When you select this function, the projector turns the image upside down for ceiling-mounted projection.

Downloaded From projector-manual.com Acer Manuals

Image (Computer / Video Mode)

Rear-Ceiling

When you select this function, the projector reverses and turns the image upside down at same time. You can project from behind a translucent screen with ceiling mounted projection.

Menu Location

Choose the Menu location on the display screen.

Sharpness

Adjusts the sharpness of the image.

- Press the ◀ to decrease the sharpness.
- Press the ▶ to increase the sharpness.

❖"Sharpness" functions is not supported under DVI and Computer mode.

H. Position (Horizontal Position)

- Press the ◀ to move the image left.
- Press the ▶ to move the image right.

V. Position (Vertical Position)

- Press the ◀ to move the image down.
- Press the ▶ to move the image up.

❖"H. Position", "V. Position", "Frequency" and " Tracking" functions are not supported under DVI and Video mode.

Frequency

"Frequency"changes the display data frequency to match the frequency of your computer's graphic card. If you experience a vertical flickering bar, use this function to make an adjustment.

Downloaded From projector-manual.com Acer Manuals

User Controls

Image (Computer / Video Mode)

Tracking

"Tracking" synchronizes the signal timing of the display with the graphic card. If you experience an unstable or flickering image, use this function to correct it.

Downloaded From projector-manual.com Acer Manuals



Audio (Computer / Video Mode)

Volume

- Press the ◀ to decrease the volume.
- Press the ▶ to increase the volume.

Mute

- Choose the "On" to turn mute on.
- Choose the "Off" to turn mute off.

Power On/Off Volume

Choose this function to adjust volume when power on/off.

Alarm Volume

Choose this function to adjust volume when there are errors of the projector.

Timer Volume

Choose this function to adjust volume when timer function is enable and time is up.

Downloaded From projector-manual.com Acer Manuals

User Controls

Management (Computer / Video Mode)

ECO Mode

Choose "On" to dim the projector lamp which will lower power consumption, extend the lamp life and reduce noise. Choose "Off" to return normal mode.

Auto Shutdown(Minutes)

The projector will auto shutdown while there is no signal input after the setting time.

Timer Start

Press the ▶ to start/stop timer.

Timer Period

Press the ▶ to adjust timer period.

Timer Display

Press the ▶ to choose timer display mode on the screen.

Timer Location

Choose the timer location on the screen.

Lamp Hour Elapse

Displays the lamp's elapsed operating time (in hours).

Lamp Hour Reset

Press the ▶ button after choosing "Yes "to turn the lamp hour counter to 0 hours.

Downloaded From projector-manual.com Acer Manuals

Management (Computer / Video Mode)

Lamp Reminding

Choose this function to show or to hide warning message when the changing lamp message is displayed. The message will show up 30 hours before end of life.

Start-up Screen

Use this function to slect your desired start-up screen. If you change the setting from one to another, when you exit the OSD menu, the new setting will take effect.

- Acer : The default start-up screen of Acer projector.
- User : The user customized start-up screen, which is down loaded from PC to projector via the USB cable and ***Acer eOpening Management*** utility (refer to the description of below section).

Downloaded From projector-manual.com Acer Manuals

Management (Computer / Video Mode)



Acer eOpening Management is a PC utility for user to change the default start-up screen of Acer projector to their desired image. You can install ***Acer eOpening Management*** from the bundled CD. Connect the projector to your PC with the bundled USB cable then execute ***Acer eOpening Management*** utility to download your desired image from your PC to projector. Before the download starts, the projector must enter "Download Mode" first. Please follow the instruction below to enter "Download Mode".

1. If the projector was turned on, press power button twice to turn off the projector.
2. Unplug the AC power cord from the projector.
3. Press and hold "Menu" and " ⏻ " buttons simultaneously then plug the AC power cord to the projector.
4. When Temp and Lamp LEDs are turned light, release both buttons, projector enters download mode.
5. Please make sure the USB cable has been connected to the projector from your PC.

Reset

Press the button after choosing "Yes" to return the display parameters on all menus to the factory default settings.

Downloaded From projector-manual.com Acer Manuals

Troubleshooting

If you experience trouble with the projector, refer to the following information. If the problem persists, please contact your local reseller or service center.

Problem: No image appears on screen.

- Ensure all the cables and power connections are correctly and securely connected as described in the "Installation" section.
- Ensure the pins of connectors are not crooked or broken.
- Check if the projection lamp has been securely installed. Please refer to the "Replacing the lamp" section.
- Make sure you have removed the lens cap and the projector is switched on.
- Ensure that the "Hide" feature is not enabled.

Problem: Partial, scrolling or incorrectly displayed image.

- Press the "Resync" button on the Remote Control.
- If you use a PC:
  If the resolution of your computer is higher than 800 x 600.
  Follow the steps outlined below to reset the resolution.

  For Windows 3.x:
  1. In the Windows Program Manager, click the "Windows Setup" icon in the Main group.
  2. Verify that your display resolution setting is less than or equal to 800 x 600.

  For Windows 95, 98, 2000, XP:
  1. Open "My Computer" icon, the "Control Panel" folder, and then double click on the "Display" icon.
  2. Select the "Setting" tab.
  3. In the "Desktop Area" you will find the resolution setting. Verify that the resolution setting is less than or equal to 800 x 600 resolution.

  If the projector is still not projecting the whole image, you will also need to change the monitor display you are using. Refer to the following steps.

  4. Follow the above steps 1-2. Click on the "Advanced Properties" button.
  5. Select the "Change" button under the "Monitor" tab .

Downloaded From projector-manual.com Acer Manuals

6. Click on “Show all devices”. Then select “Standard monitor types” under the “Manufacturers” box ; choose the resolution mode you need under the “Models” box.
7. Verify that the resolution setting of the monitor display is less than or equal to 800 x 600.

- If you are using a Notebook PC:
  1. You are required to implement the above steps of resolution setting of the computer first.
  2. Switch the Notebook PC display to the “external display only” or “CRT only” mode.
- If you experience difficulty in changing resolutions or your monitor freezes, restart all the equipment and the projector.

Problem: The screen of the Notebook or PowerBook computer is not displaying your presentation.

- If you are using a Notebook PC:
  Some Notebook PCs may deactivate their screens when a second display device is in use. Refer to your computer’s documentation for information on how to reactivate the monitor display.
- If you are using an Apple PowerBook:
  In Control Panels, open the PowerBook Display to select Video Mirroring “On”.

Problem: Image is unstable or flickering

- Use “Tracking” to correct it. Refer to page 24.
- Change the monitor color setting from your computer.

Problem: Image has vertical flickering bar

- Use “Frequency” to make an adjustment. Refer to page 23.
- Check and reconfigure the display mode of your graphic card to make it compatible with the product. Refer to page 28.

Problem: Image is out of focus

- Adjusts the Focus Ring on the projector lens. Refer to page 14.
- Make sure the projection screen is between the required distance 4.9 to 39.4 feet (1.5 to 12.0 meters) from the projector.

Downloaded From projector-manual.com Acer Manuals

Problem: The image is outstretched when displaying 16:9 DVD.

The projector automatically detects 16:9 DVD and adjusts the aspect ratio by digitizing to full screen with 4:3 default setting.

If the image is still outstretched, you will also need to adjust the aspect ratio by referring to the following:

- Please select 4:3 aspect ratio type on your DVD player if you are playing a 16:9 DVD.
- If you can't select 4:3 aspect ratio type on your DVD player, please select 4:3 aspect ratio in the on screen menu.

Problem: Image is reversed.

- Select "Image" from the OSD and adjust the projection direction. See page 22.

Problem: Lamp burns out or makes a popping sound

- When the lamp reaches its end of life, it will burn out and may make a loud popping sound. If this happens, the projector will not turn on until the lamp module has been replaced. To replace the lamp, follow the procedures in the "Replacing the Lamp". See page 33.

Problem: LED lighting message

Message	Power LED		Temp LED	Lamp LED
	Red	Blue		
Standby State (Input power cord)	Slow Flashing	○	○	○
Lamp lighting	○	☼	○	○
Power on	○	☼	○	○
Power off (Cooling)	Quick Flashing	○	○	○
Error (Lamp fail)	○	○	○	☼
Error (Thermal fail)	○	○	☼	○
Error (Fan lock fail)	○	○	Flashing	○
Error (Over Temp.)	○	○	☼	○
Error (Lamp Breakdown)	○	○	○	☼

☼ =>Light On ○ =>Light Off

Downloaded From projector-manual.com Acer Manuals

Problem: Message Reminders

- "Lamp is approaching the end of its useful life in full power operation. Replacement Suggested!" will be shown about 10 seconds when lamp life is going to deplete.
- "Projector Overheated. Lamp will automatically turn off soon." will be shown when the system temperature is over heat.
- "Fan fail. Lamp will automatically turn off soon." will be shown when the fan is out of order.

Downloaded From projector-manual.com Acer Manuals

Replacing the lamp

The projector will detect the lamp life itself. It will show you a warning message "Lamp is approaching the end of its useful life in full power operation. Replacement Suggested!" When you see this message, changing the lamp as soon as possible.

Make sure the projector has been cooled down for at least 30 minutes before changing the lamp.

Warning: Lamp compartment is hot! Allow it to cool down before changing lamp!



Warning: To reduce the risk of personal injury, do not drop the lamp module or touch the lamp bulb. The bulb may shatter and cause injury if it is dropped.

Lamp Changing Procedure:

1. Turn the power off the projector by pressing the Power button.
2. Allow the projector to cool down at least 30 minutes.
3. Disconnect the power cord.
4. Use a screwdriver to remove the screw from the cover. ❶
5. Push up and remove the cover. ❷
6. Remove the 2 screws from the lamp module. ❸
7. Pull out the lamp module. ❹

To replace the lamp module, reverse the previous steps.

Downloaded From projector-manual.com Acer Manuals

Appendices

Specifications

The specs specified below are subject to change without notice. Regarding the final specs, please refer to Acer accounced marketing specs.

Light Valve	- Single Chip DLP™ Technology by Texas Instruments
Lamp	- 200W User Replaceable Lamp
Number of Pixels	- 800 pixels(H) X 600 lines(V)
Displayable Color	- 16.7M colors
Contrast Ratio	- 2000:1 (Full On/Full Off)
Uniformity	- 85%
Noise Level	- 31dB(A)(standard mode / 27dB(A)(ECO mode)
Projection Lens	- F/2.7~3.0 f=21.83~23.81mm with 1.1x Manual zoom lens
Projection Screen Size (Diag.)	- 34.7 to 304.9 inches (0.88 to 7.75 meters) Diagonal
Projection Distance	- 4.9 to 39.4 feet (1.5 to12.0 meters)
Video Compatibility	- NTSC 3.58/NTSC 4.43/PAL/SECAM and HDTV compatible - Composite video & S-Video capability
H. Frequency	- 31.5kHz~100kHz horizontal scan
V. Frequency	- 56Hz~85Hz vertical refresh
Power Supply	- Universal AC input 100-240V ; Input Frequency 50/60Hz
I/O Connectors	- Power: AC power input socket - VGA Input: ▪ One DVI connector for Digital signal with HDCP (For PD100D only) ▪ One 15-pin D-sub for VGA, component and HDTV signal - VGA Output: One 15-pin D-sub for VGA output - Video Input: ▪ One Composite video RCA input ▪ One S-Video input - One 5V DC output jack for attached dongle device (For PD100 only) - USB:One USB connector - Audio Input: One phone jack for audio input
Weight	- 4.85 lbs (2.2kg)
Dimensions (W x H x D)	- 9.1x 9.4 x 4.8 inches (230 x 238 x 122.8 mm)
Environmental	- Operating Temperature: 41~95°F (5~ 35°C) Humidity: 80% maximum (Non-condensing) - Storage Temperature: -4~140°F (-20~60°C) Humidity: 80% maximum (Non-condensing)
Safety Regulation	- FCC Class B, CE Class B, VCCI-II, UL, cUL, TÜV-GS, C-tick, PSB, PSE, CB Report, CCC

Downloaded From projector-manual.com Acer Manuals

Compatibility Modes

Mode	Resolution	(ANALOG)		(DIGITAL)	
		V.Frequency (Hz)	H.Frequency (kHz)	V.Frequency (Hz)	H.Frequency (kHz)
VESA VGA	640 x 350	70	31.5	70	31.5
VESA VGA	640 x 350	85	37.9	85	37.9
VESA VGA	640 x 400	85	37.9	85	37.9
VESA VGA	640 x 480	60	31.5	60	31.5
VESA VGA	640 x 480	72	37.9	72	37.9
VESA VGA	640 x 480	75	37.5	75	37.5
VESA VGA	640 x 480	85	43.3	85	43.3
VESA VGA	720 x 400	70	31.5	70	31.5
VESA VGA	720 x 400	85	37.9	85	37.9
VESA SVGA	800 x 600	56	35.2	56	35.2
VESA SVGA	800 x 600	60	37.9	60	37.9
VESA SVGA	800 x 600	72	48.1	72	48.1
VESA SVGA	800 x 600	75	46.9	75	46.9
VESA SVGA	800 x 600	85	53.7	85	53.7
VESA XGA	1024 x 768	60	48.4	60	48.4
VESA XGA	1024 x 768	70	56.5	70	56.5
VESA XGA	1024 x 768	75	60.0	75	60.0
VESA XGA	1024 x 768	85	68.7	85	68.7
VESA SXGA	1152 x 864	70	63.8	70	63.8
VESA SXGA	1152 x 864	75	67.5	75	67.5
VESA SXGA	1280 x 1024	60	63.98	60	63.98
MAC LC 13″	640 x 480	66.66	34.98	***	***
MAC II 13″	640 x 480	66.68	35	***	***
MAC 16″	832 x 624	74.55	49.725	***	***
MAC 19″	1024 x 768	75	60.24	***	***
MAC	1152 x 870	75.06	68.68	***	***
MAC G4	640 x 480	60	31.35	***	***
i MAC DV	1024 x 768	75	60	***	***
i MAC DV	1152 x 870	75	68.49	***	***

Downloaded From projector-manual.com Acer Manuals